



615

Fresa elicoidale positiva in metallo duro integrale con rompitruciolo



HW



D	L1	L2	LT	S	Z	COD. RH
12	95	45	150	12	3	06151200R0
14	95	45	150	14	3	06151400R0
16	95	45	150	16	3	06151600R0
18	95	45	150	18	3	06151800R0
20	95	45	150	20	3	06152000R0



Up - cut solid carbide spiral bit with chip - breaker.




Fresa helicoidal positiva de metal duro macizo con rompevirutas.



Fraise hélicoidale positive en carbure massif avec brise - copeaux.




Hartmetall - massive - Oberfräser mit positiven Spiralschneiden und mit Spanbrechern.




HW

D	L1	L2	LT	S	Z	COD. RH
16	95	23	150	16	2	0615F160R0


Ricambi / Spare parts / Rechanges / Repuestos / Ersatzteile



B	H	a	COD.
23	7	1.5	048115FA00



B	H	a	COD.
23	7	1.5	048115FB00



M x B	COD.
3 x 4	048074F304



COD.	
TORX T9	048020F000



Router cutter with throwaway knives and chip - breaker.




Fresa router con cuchillas y rompevirutas.



Fraise usinage boîtier de serrure avec plaquettes à jeter avec brise - coupeaux.



Oberfräser mit Messern und Spanbrechern.



HW



D	L	LT	S	Z	COD. RH
14	50	110	14	3	0615A140R0
16	55	110	16	3	0615A160R0



Up - cut solid carbide spiral bit.



Fresa helicoidal positiva de metal duro macizo.




Fraise hélicoidale positive en carbure massif.



Hartmetall - massive - Oberfräser mit positiven Spiralschneiden.

615 - B

Fresa elicoidale positiva in metallo duro integrale con rompitruciolo



HW



D	L	LT	S	Z	COD. RH
14	58	110	14	3	0615B140R0
16	55	110	16	3	0615B160R0



Up - cut solid carbide spiral bit with chip - breaker.



Fraise hélicoïdale positive en carbure massif avec brise - copeaux.



Fresa helicoidal positiva de metal duro macizo con rompevirutas.



Hartmetall - massive - Oberfräser mit positiven Spiralschneiden und mit Spanbrechern.